

Post-flight Checklist

A. Aircraft

- i. Unplug flight battery.
- ii. Unplug video transmitter battery.
- iii. Check aircraft temperatures of motors and other electronics.
- iv. Check hardware on aircraft to ensure tightness.
- v. Check propellers for any indications of chips, cracks, or wear beyond safe serviceability.
- vi. Store aircraft in case.
- vii. Put batteries back into storage cases.

B. Batteries

- i. Check temperature of batteries.
- ii. Check batteries for any indication of swelling.
- iii. Check overall voltage of battery packs.
- iv. Check individual cell voltages in battery packs.
- v. Put batteries on storage charge.

C. Camera

- i. Verify that recording has stopped.
- ii. Turn off camera.
- iii. Remove camera from gimbal.

D. Radios

- i. Turn off radios.
- ii. Put radios back into cases.

E. Ground stations

- i. Turn off ground stations.
- ii. Unplug batteries from ground stations.
- iii. Check antennas on ground stations for serviceability .
- iv. Pack ground stations into cases.

F. Other

- i. Clean up all trash and debris in area.
- ii. Notify property owners of departure.